



**Part No. ALL10221**  
**ALL10222**

## Clamp-On Kits

Clamp-on kit eliminates welding of tabs to chassis. Clamps have .600" holes designed to install ALL10219 window net installation kit to chassis tubing.

<b>Part No.</b>	<b>Description</b>
ALL10221.....	Kit For 1-1/2" Tubing
ALL10222.....	Kit For 1-3/4" Tubing



### Replacement Components:

ALL99160.....	1-1/2" Clamp-On Bracket Fixed
ALL99161.....	1-1/2" Clamp-On Bracket Swivel
ALL99162.....	1-3/4" Clamp-On Bracket Fixed
ALL99163.....	1-3/4" Clamp-On Bracket Swivel

**Allstar Performance 8300 Lane Dr., Watervliet, MI 49098**  
**Phone: (269) 463-8000 Fax: (800) 772-2618 [www.allstarperformance.com](http://www.allstarperformance.com)**