



Installation Instructions for Stud Assembly

Part Number: 20180-3A

To Install Stud Assembly (20180-3A)

**Do not unscrew the needle when removing
or installing the stud adapter!**

1. Rotate knob counterclockwise until it hits the stop.
2. Remove allen screw, knob, retainer clip, jam nuts, upper washer and upper grommet to install shock in chassis.
3. Reinstall the upper grommet and washer with the chassis between the upper and lower grommets.
4. Install jam nut and tighten snugly against washer. Grommets should have pre-load, but not be excessively distorted.
5. Install second jam nut and tighten it against the first to lock the two nuts against each other.
6. Reinstall clip, knob, and allen screw.

