



232 Branford Rd.
North Branford, CT 06471
Orders: 203.481.9460
Tech: 203.481.9943
Fax: 203.481.9641

Product Instructions

Power Series Oil Pan Installation

To ensure the best results, we recommend the following:

- 1) Please refer to the Canton oil pan installation instructions included with these instructions for general installation and sealing procedures, and refer to the additional instructions listed here for steps specific to your Canton Racing Power Series Oil Pan.
- 2) Remove the 1/2" NPT plugs along the pan rail. Inspect the threads and apply Teflon Tape to the threads upon reinstallation.
- 3) Apply a thin bead of silicone to the entire pan rail and set gasket onto the pan rail. Apply a thin bead onto the block side of the gasket and set pan onto the block.
- 4) Install the pan bolts or studs along the pan rail. For the mounting holes corresponding to the plugs, use a long 3/8" drive extension. DO NOT torque the pan at this time. Allow the silicone to cure.
- 5) Once the silicone is cured, torque the pan down according to the specs on the oil pan installation instructions.
- 6) Re-install the 1/2" NPT plugs back into the pan. (NOTE: DO NOT over tighten the plugs. These plugs are NPT thread which means they are designed with a taper and will only thread in so far. Over tightening can result in damage to the threads as well as leaking from the plug.)

Installation of your Canton Racing Power Series Oil Pan is now complete.

