



232 Branford Rd. North Branford, CT 06471

Orders: 203-481-9460 Tech: 203-481-9943 Fax: 203-481-9641

Accusump Indicator LED Install Notes

24-295 Accusump Indicator LED Light Kit





- terminal connection. **To Ground** Backside of 2. Remove connection from the From LED Light valve to the pressure switch. Switch
 - 3. Install dual spade connector to the pressure switch side.
 - 4. Re-attach wire from the valve to the pressure switch and add wire to the LED Light.
 - 5. Be sure to assemble the LED Light and plate prior to wiring.
 - 6. Attach the other side of the LED to ground.
 - 7. Re-attach negative battery terminal connection.



Note: There are extra connectors included in this kit.

www.CantonRacingProducts.com