




Hybrid Sizing - Chest Strap with Driving Suit On



1. Measure around chest below pectoral muscles.
2. Measure with driving suit. If not available add 1" to measurement.
3. Take measurement with tape placed against driver with out any slack and with out pulling the tape tight.
4. Once measurement has been determined refer to size charts for device size selection. Call customer service at 800-654-7223 if unsure.